Installation and Maintenance Instructions for LSVC Level Switch



Make sure you thoroughly understand the contents of this manual before installing and using this level switch.

# LSVC

# **Level Switch**



Manufactured by:

# CONTENTS

SECTION		PAGE
1	Description	3/6
2	Technical data	3/6
3	Wire DC output, to drive relays PLC-S	4/6
4	Accessories	4/6
5 5.1	Installation Switching point and switch differential	4/6 5/6
6	Electrical connections	6/6
7	Adjusting	6/6
8	Maintenance	6/6
9	Warranty	6/6

Manufactured by:

## 1. DESCRIPTION:

The LSVC is a robust and compact *micro processor based* level switch based on a vibrating probe. The piezo crystal is excited and kept in resonance by an electronic circuit. The process liquid, when reaching the probes changes the frequency of the vibration. The vibration frequency in a liquid is lower than in air or gas.

The LSVC is suitable for all kind of liquids. Due to the high vibration frequency combined with the very rugged probe, the function will not be influenced by turbulence, air bubbles or system vibration. If the level switch is used on high viscosity fluids, the mounting position is very important. The position of the tuning forks have to be so that the fluid easily drops of.

A marking on the hexagonal neck on top of the process connection shows the position of the tuning fork.

## 2. TECHNICAL DATA

LSVC				
Maximum pressure	40 bar			
Probe length	47 mm up to 3 meters			
Material wetted parts	AISI 316			
Liquid temperature range	-10+90°C (tested) -40+100°C (limits)			
Ambient temperature	0+70°C (tested) -40+70°C (limits)			
Liquid density	≥ 0.7 kg/dm³			
Liquid viscosity	≤ 10.000 mm²/s (c St)			
Respons time	2 seconds			
Output mode indication	Status LED (not with the cable version, output 4)			
Hirschmann connector	4-Pole (Standard) Polyamide			
M12 Connector	Option (extra price)			

Manufactured by:

# 3. 3-WIRE DC OUTPUT, TO DRIVE RELAYS OR PLC:


Version	3 wire DC			
Cable gland	PG 9			
Protection Grade	IP 65	IP 68 (with cable version)		
Output	PNP, 3-wire			
Output protection	Over voltage and sho Thermal protection	Over voltage and short circuit protected		
Supply voltage	12 40 Vdc			
Consumption	< 0,35 W			
Voltage drop in switched-on state	< 4,5 Vdc			
Current load (maximum values) I <sub>max</sub> = 350 mA DC / U <sub>max</sub> = 40 Vdc		<sub>ax</sub> = 40 Vdc		
Residual current (in switchedoff state)	< 100 μA			

# 4. ACCESSORIES:

Various hygienic process connections are available (Milk coupling, Tri-Clamp and more). The standard process connection is 1" BSP thread. Various weld-on nipples, also the standard sanitary 1" BSP weld- on nipple are available on request. The 1" BSP hygienic weld-on nipples are available in two versions, ø 65 mm (article no. 10197) and ø 48 mm (Article no: 10189).

# 5. INSTALLATION:

Avoid mechanical damage.



Manufactured by:


## Low Viscous liquids


In applications where the medium is **<u>not</u>** viscous, all mounting positions as shown on the right are possible.

#### High Viscous fluids.

On applications with viscous media is recommended for the "tuning fork" only vertically to mount.

## Installing options





**Threaded version** 

Critical distances (x<sub>min</sub> > 5 mm)





# 5.1 SWITCHING POINT AND SWITCHING HYSTERESIS:



## (For water at 25°C)

Switching point as well as the switch differential depends on liquid density and mounting position. Fork-tunes must be parallel to the direction of flow.

# 6. ELECTRICAL CONNECTIONS:

## Output: 3

PNP mode: N.O. out	PNP mode: N.C. out	
1 = +	1 = -	
2 = -	2 = +	
3 = PNP	3 = PNP	

#### Manufactured by:

Output: 4 (with mounted cab PNP mode: N.O. out	ole) PNP mode: N.C. out
FNF mode. N.O. out	FNF IIIOde. N.C. Oul
Red = +	Red = -
Bleu = -	Bleu = +
Yellow= earth	Yellow= earth
Black = PNP (N.O.)	Black = PNP (N.C.)

## 7. ADJUSTMENT:

Check the connection of the wires and the position of vibrating probes. After connection and power up the level switch is operational. Operating diagram of the LSVC:

Power supply	Probe	Operating mode	Status LED	Output
ON	Covered	High level	Red	24 Vdc
		Low level	Green	0 Vdc
	┍╴ <mark>╘</mark> ┲┨	High level	Green	0 Vdc
	Free	Low level	Red	24 Vdc

## 8. MAINTENANCE and REPAIR:

The LSVC is maintenance free. When the tuning fork should be cleaned, it should be done very carefully without mechanical force to the Tuning fork!

## 9. WARRANTY:

## The warranty is 1 year from delivery date.

Ashcroft does not accept liability for consequential damage of any kind due to use or misuse of the LSVC Level Switch.Warranty will be given, to be decided by the manufacturer. The Level Switch must be shipped prepaid to the factory on manufacturer's authorization. **The Tuning fork should not be damaged.** 

## Ashcroft reserves the right to change its specifications at any time, without notice.

Manufactured by: